

Removing the Original Poppet

Step 1: Remove the pin from the poppet by driving out the pin with a small punch or hammer.



Removing the Original Poppet

Step 2: Once the pin has been removed slide the poppet and o-ring from the stem.



Installing the New Poppet & O-ring

Step 1: Take the new o-ring from the kit, lube it and slide it on the stem, next take the new poppet from the kit and slide it over the stem and on top of the o-ring.



Installing the New Poppet and O-ring

Step 2: Align the hole in the new poppet with the hole in the stem.



Installing the New Poppet and O-ring

Step 3: Take the new shaft pin from the kit, insert it and tap it in place until it is flush with both sides.



Installing the New Poppet and O-ring

Step 4: Replacement is now complete.